



## WORKING TOWARDS A PEACEFUL REST FOR DRIVERS



REGISTER FOR FREE  
[WWW.NOMADPOWER.EU](http://WWW.NOMADPOWER.EU)



### NOMADPOWER

Electricity supply for temperature controlled road transport during breaks and overnight stays.

Drivers often have to wait or rest at motorway services. During the duration of their stay, refrigerated transport drivers are having to run their noisy and polluting diesel generators to preserve their cargoes. Thanks to NomadPower's newly installed power connection points, drivers can now refrigerate with quiet, clean and cheap electric power.

NomadPower is a sustainable alternative to running the diesel generator overnight and uses 100% renewable electricity. NomadPower is now available in seven Moto sites. On the continent NomadPower can be found in Benelux, Germany, Italy and Spain. Please visit [www.nomadpower.eu](http://www.nomadpower.eu) to find out more.

#### NOMADPOWER BENEFITS



100% renewable solar power



A better night's sleep



No emissions of particulates, soot or greenhouse gases



Competitively priced



#### INTERESTED IN NOMADPOWER?

Please register for free at [www.nomadpower.eu](http://www.nomadpower.eu), connect a cable with a 5-pole plug (32A, 400V) and start cooling today!

#### NOMADPOWER AS PROVEN SERVICE

Supported by the European Union, NomadPower has been working on the roll-out of the largest truckpower network in Europe. NomadPower is now available in over 40 locations with hundreds of power connection points. Each day, more truckers use NomadPower and have a quiet and clean workplace.

+44 203 868 9493

[info@nomadpower.eu](mailto:info@nomadpower.eu)

[www.nomadpower.eu](http://www.nomadpower.eu)

# Locations

## UK

Lymm Lorry Park, Moto Services, M6 Exit 20 / M56 Exit 9  
Doncaster North, Moto Services, M18 Exit 5  
Donington, Moto Services, M1 Exit 23A  
Cherwell Valley, Moto Services, M40 Exit 10  
Toddington NB, Moto Services, M1 between Exit 11 & Exit 12  
Toddington SB, Moto Services, M1 between Exit 11 & Exit 12  
Thurrock, Moto Services, M25 between Exit 30 & Exit 31

## THE NETHERLANDS

Emmen, Truck Centrum Emmen, A37 Exit 6  
Rogat, Wegrestaurant De Raket, A28 Exit 34  
Rotterdam Albrandswaard, Routiers Eemhaven, A15 Exit 18  
Zevenbergschen Hoek, De Gouden Leeuw, A16 Exit 18  
Roosendaal, Secured truckparking Borchwerf, A17 Exit 20  
Bergen op Zoom, Partner Logistics (Restricted parking)  
Waalwijk, Trucksafe, A59 Exit 37

## BELGIUM

Meer, IDS Truckstop Joost, A1 Exit 1  
Heusden-Zolder, Truckstop 26bis, A13 Exit 26  
leper, Partner Logistics (Restricted parking)

## ITALY

Vipiteno, A22, Exit Autoparco Sadobre  
Trento, A22, Exit Interporto Trento  
Bologna, A13, Exit Interporto Bologna  
Colleferro, A1, Exit Truckvillage Colleferro  
Piacenza, A21, Exit GA Terminal Piacenza (opening Q3 2017)

## GERMANY

Lauenau, Maxi Autohof, A2 Exit 37  
Theeßen, Euro Rastpark, A2 Exit 75  
Lippetal, Euro Rastpark, A2 Exit 19  
Guxhagen, Euro Rastpark, A7 Exit 81  
Homburg, 24 Autohof, A7 Exit 84  
Neuberg, 24 Autohof, A45 Exit 41  
Rheinböllen, Aral Autohof Elbert, A61 Exit 45  
Waldlaubersheim, Euro Rastpark, A61 Exit 47  
Werneck, Euro Rastpark, A70 Exit 3  
Geiselwind, Autohof Strohofer, A3 Exit 76  
Neuhaus, Autohof Bergler, A93 Exit 20  
Bad Rappenau, 24 Autohof, A6 Exit 35  
Crailsheim-Satteldorf, Euro Rastpark, A6 Exit 46  
Regensburg-Ost, Euro Rastpark, A3 Exit 101  
Schweitenkirchen, Euro Rastpark, A9 Exit 66  
Jettingen-Scheppach, Euro Rastpark, A8 Exit Scheppach  
Mühdorf, 24 Autohof, A94 Exit 20

## SPAIN

La Jonquera, Red Tortuga, AP7 Exit 2  
Girona, Parking Padrosa, AP7 Exit 3  
Burgos, Castillo El Burgos, A231 Exit 34

# How does it work?

## 1. REGISTRATION

Register for free at [www.nomadpower.eu](http://www.nomadpower.eu)  
After registration all drivers and the planning department can switch on or switch off any of the NomadPower connection points in the following ways:

- > By smartphone (via the NomadPower app)
- > Via [www.nomadpower.eu](http://www.nomadpower.eu)
- > Or by telephone (+44 20 3695 3273)

As a registered user you have detailed real time insight in the usage of NomadPower by all drivers via the NomadPower website.

## 2. STARTING THE POWER SUPPLY

After arriving at one of the participating motorway services, follow signs to one of the NomadPower parking bays. Plug in the power cable (5-pole plug 32A, 400V) to one of the NomadPower connection points. Next step is to activate the power supply via smartphone, Internet or telephone by quoting the 5-digit number. After a few seconds the power supply will start.

## 3. STOPPING THE POWER SUPPLY

After a quiet night's sleep, simply end the power supply in the same way by using your smartphone, Internet or telephone. If the driver forgets to deactivate the NomadPower connection point, the power supply will stop immediately after unplugging the power cable. The driver and/or the planning department receive a complimentary text message or email notification as soon as the cable has been disconnected.

## 4. PAYMENT

You will receive a detailed monthly invoice showing dates, usage and locations. You can even specify your own internal cargo number or other reference number with each power supply so that you can allocate costs to specific customers. For NomadPower rates, please check the tariffs on [www.nomadpower.eu](http://www.nomadpower.eu)

☎ +44 203 868 9493

✉ [info@nomadpower.eu](mailto:info@nomadpower.eu)

🌐 [www.nomadpower.eu](http://www.nomadpower.eu)

